


# SSL®

## USER'S MANUAL

### SDC24USA

MP3-COMPATIBLE CD AM/FM RECEIVER



# CONTENTS

---

|                                            |     |
|--------------------------------------------|-----|
| Precautions.....                           | 1   |
| How to Handle Discs.....                   | 1   |
| Lithium Battery Cell Warnings.....         | 1   |
| Installation .....                         | 2   |
| Prepare Radio.....                         | 2   |
| Mount Radio.....                           | 2-3 |
| Wiring Connections.....                    | 3   |
| Removal of the Main Unit .....             | 3   |
| Control Panel Button Locations.....        | 4   |
| General Operation .....                    | 5   |
| Turn Unit On/Off.....                      | 5   |
| Adjust Volume (VOL) .....                  | 5   |
| Adjust Menu Options (SEL).....             | 5   |
| Set the Clock (CLK) .....                  | 5   |
| Change the Source (SRC).....               | 5   |
| Loudness On/off (LOUD) .....               | 5   |
| Preset Equalizer (EQ).....                 | 5   |
| Mute On/off (MUTE) .....                   | 5   |
| Reset System (RESET) .....                 | 5   |
| Radio Operation .....                      | 6   |
| Switch Between US and EU Frequency .....   | 6   |
| Change Bands (BAND).....                   | 6   |
| Manual Tuning ( << / >> ).....             | 6   |
| Auto Seek Tuning ( << / >> ).....          | 6   |
| Automatic Music Search (AMS).....          | 6   |
| Store/Recall Preset Stations (1 - 6) ..... | 6   |
| Local/DX (LOC) .....                       | 6   |
| Stereo/Mono (ST) .....                     | 6   |
| Disc/USB/Card Operation.....               | 7   |
| Insert Disc/USB/SD.....                    | 7   |
| Eject Disc/USB/SD.....                     | 7   |
| Play/Pause.....                            | 7   |
| Next/Previous Track.....                   | 7   |
| Fast Forward/Backward .....                | 7   |
| Track Search.....                          | 8   |
| Track/Folder Navigation .....              | 8   |
| Remote Control .....                       | 9   |
| Remove Insulating Sheet.....               | 9   |
| Replace Lithium Battery Cell.....          | 9   |
| Remote Control Operation .....             | 9   |
| Button Names and Locations.....            | 10  |
| Troubleshooting .....                      | 11  |
| Specifications .....                       | 12  |

# PRECAUTIONS

---

## How to Handle Discs

- Handle a disc by its edges. Do not touch the playing side.
- Before inserting a disc, wipe the disc outward from the disc center with a clean, soft, dry and lint-free cloth. Do not use solvents or thinners such as petrol/benzene or cleaners.
- After removing a disc from the disc slot, place the disc in a sleeve or case to keep it clean and prevent scratches.
- Do not stick paper or tape on the disc surface. If there is glue (or adhesive) on the disc surface, remove it before using the disc.



## Lithium Battery Cell Warnings


- Cell leakage may cause damage to the remote control.
- Do not throw cells into fire, as this may cause an explosion.
- Keep battery cells out of reach of children.

# INSTALLATION


---

## Prepare Radio

1. Before you begin, disconnect the battery negative terminal.
2. Remove the transport screws.



3. Remove chassis from the mounting sleeve.




## Mount Radio

Refer to the "Installation Diagram" to install the unit.

1. Bend the tabs on the mounting sleeve, where necessary, to ensure than the front part of the main unit will remain fixed into the vehicle dash opening.
2. Insert radio into the mounting sleeve.
3. Use a metal strap to secure the rear part of the chassis using the hardware indicated.
4. Make wiring connections, as illustrated in the "Wiring Diagram."
5. Install the plastic trim out.

# INSTALLATION (CONT.)


## INSTALLATION DIAGRAM



- Only use speakers with 4 ohms impedance.
- Do not attach the control panel to the chassis before wiring is complete.
- The maximum current of the Amp Remote trigger is 200mA.

## Wiring Connections

### WIRING DIAGRAM




**CAUTION**  
+12V DC  
NEGATIVE  
GROUND

## Removal of the Main Unit

1. Remove the metal strap from the main unit.
2. Remove the plastic trim out from the main unit.
3. Insert a bracket key into the left and right side of the main unit and draw the unit out of the mounting sleeve.

# CONTROL PANEL BUTTON LOCATIONS



1. POWER/SRC (source) button
2. SEL (select/menu) button and VOL (volume) knob
3. BAND button
4. AMS (automatic music search) button
5. >|| or 1 button
6. INT (intro) or 2 button
7. RPT (repeat) or 3 button
8. RDM (random) or 4 button
9. -10 or 5 button
10. +10 or 6 button
11. CLK (clock) button
12. |<< button
13. >>| button
14. MUTE button
15. EJECT button
16. RESET button
17. AUX IN (auxiliary input) jack
18. USB port
19. SD Card slot
20. Disc slot

# GENERAL OPERATION

---

## Turn Unit On/Off

Press the power (⏻) /SRC button to turn on the unit. Press and hold it to turn off the unit.

Press the power (⏻) button on the remote control to turn the unit on or off.

## Adjust Volume (VOL)

Rotate the **VOL** knob on the front panel or press the **VOL+/-** button on the remote control to increase or decrease the volume level.

## Adjust Menu Options (SEL)

- Press the **SEL** button repeatedly to cycle through the following adjustable audio functions: BASS, TREBLE, BALANCE, FADER, EQ OFF, LOUD OFF, DX, STEREO and VOLUME.
- Press and hold the **SEL** button to access these additional functions: VOL LAS/ADJ, AREA EU/US, Clock 12/24, and BEEP ON/OFF.
- Rotate the **VOL** knob on the front panel or press the **VOL+/-** button on the remote control to adjust the selected item.

## Set the Clock (CLK)

1. To display clock time, press the **CLK** button.
2. To set clock time, press and hold the **CLK** button and the hour will flash.
3. Press the **I<<** or **>>I** button or press the **NEXT** or **PREV** button to adjust the hour.
4. Press the **CLK** button and the minutes will flash.
5. Press the **I<<** or **>>I** button or press the **NEXT** or **PREV** button to adjust the minutes.
6. During Bluetooth mode, the clock can not be adjusted.

## Change the Source (SRC)

Press the **SRC** button to switch between RADIO, DISC, USB, CARD and AUX-IN modes.

## Loudness on/off (LOUD)

Press the **LOUD** button on the remote control to turn on the loudness to reinforce the output of bass frequencies, press again to turn it off.

## Preset Equalizer (EQ)

Press the **EQ** button on the remote control to choose a desired preset equalizer mode: OFF, FLAT, POP, ROCK, CLASS.

## Mute on/off (MUTE)

Press the **MUTE** button on the remote control to toggle mute on or off. The muted state will be also released, when the volume knob or **VOL+/-** button are used.

## Reset System (RESET)

The **RESET** button is used to reset all parameters to factory default settings.

This function may be used when the LCD does not display normally or sound is distorted, or when any of the controls are disabled. To reset your system, use a thin object with a pointed end to depress the **RESET** button.

# RADIO OPERATION

---

## Switch Between US and EU Frequency

In radio mode, press and hold the **VOL** button to select the AREA EU/US, then rotate it to switch between US (USA) and EU (Europe) frequency. The system will change the frequency setting in about 3 seconds.

## Change Bands (BAND)

Press the **BAND** button to switch between the F1 (FM1), F2 (FM2), F3 (FM3), A1 (AM1) and A2 (AM2) bands. Each band stores up to six preset stations.

## Manual Tuning (|<< / >>|)

Press and hold the >>| or |<< button to enter manual tuning mode. In manual tuning mode, press the >>| or |<< button to move the radio frequency number up or down one step.

## Auto Seek Tuning (|<< / >>|)

In standby mode or while not in manual tuning mode, quickly press the >>| or |<< buttons to move to the next/previous available station automatically.

## Automatic Music Search (AMS)

Press and hold the **AMS** button for more than 2 seconds to select six strong stations and store them in the current band. The radio will automatically scan the current frequency and enter the six strongest stations into the preset memory positions for that band. Briefly press the **AMS** button on the remote control to scan each preset station in each band.

## Store/Recall Preset Stations (1 - 6)

The radio can store 6 preset stations for each band (FM1, FM2, FM3, AM1 and AM2) for a total of 30 stored stations.

1. To memorize a station, turn the radio on and select the desired band and station.
2. Press and hold the desired preset button (numbered **1 - 6** on the face of the radio) for more than 2 seconds to save the station to that preset number.
3. Repeat for the remaining five presets on the current band and for all presets on the other four bands.
4. A stored station can be recalled at any time by choosing a band and then pressing the corresponding preset button.

## LOCAL/DX

In urban areas, most stations are strong enough and "LOCAL ON" mode should be selected. Switch to LOCAL OFF mode to search for stations with weaker signals. Press the **LOC** button on the remote control to choose local or distant reception mode.

## STEREO/MONO



FM station is received in stereo mode. However, if the signal is weak or reception is not as good as you would like, switching to MONO mode usually improves the overall sound quality. Press the **ST** button on the remote control to choose FM STEREO or MONO audio effect.



# DISC/USB/CARD OPERATION

## Insert Disc/USB/SD

- To play files on a disc, insert a disc with the label surface up into the disc slot. Playback will begin automatically.
- To play files on a USB/SD device, open the USB port cover and insert the USB/SD storage device into the USB/SD port. Playback will begin automatically.



## Eject Disc/USB/SD

- To eject a disc, first press the >|| button to stop playback. Press the ▲ (eject) button to eject the disc and then remove it.
- To eject a USB device or SD card, first press the >|| button to stop playback, then remove the storage device or card.

## Play/Pause

Press the >|| (play/pause) button to pause or resume playback.

## Next/Previous Track

- To play the next track, briefly press the **NEXT** button.
- To play the previous track, briefly press the **PREV** button.

## Fast Forward/Backward

- To fast forward, press and hold the >>| or > button.
- To fast backward, press and hold the |<< or < button.

## Introduction Scan

Press the **INT** button to play the first 10 seconds of each track, press again to stop the introduction scan and play the current track.

## Repeat the Same Track

Press the **RPT** button to play the current track repeatedly, press again to stop the repeat playback and resume normal playback.

## Playing all tracks in random

Press the **RDM** button to play all tracks in random order, press again to cancel this function.

# DISC/USB/CARD OPERATION

---

## Track Search

During CD, USB or SD playback, press the **AMS** button to select one of the following 3 track search modes:

- 1) NUM SCH (Searching by track number)
- 2) DIR SCH (Searching by directory number)
- 3) FILE SCH (Searching by track or file name)

### 1) NUM SCH (Searching by track number)

a) In playback of CD or files with MP3 format, press the **AMS** button once to access the track or file number searching mode which allow you to quickly find a specific track or MP3 file by its serial number, and the "NUM SCH" and "NUM \*\*\*" will appear on the LCD display in sequence, and the first symbol "\*" will blink.

b) Rotate the **VOL** knob to select the number of your favorite track or file with high speed.

c) Finally press the **SEL** button to confirm and play the selected file.

### 2) DIR SCH (Searching by directory number)

The folder search mode allows you to quickly find an MP3 track or file under a specific group folder.

a) In playback of files with MP3 format, press the **AMS** button twice, the "DIR SCH" will be shown on the LCD display.

b) Rotate the **VOL** knob to select a desired folder.

c) Press the **SEL** button to play the first track or file of the selected folder.

### 3) FILE SCH (Searching by track or file name)

This track or file name search function allows you to quickly find an MP3 title by its name.

a) Press the **AMS** button three times, the "FILE SCH" and "\*-----" will be shown on the LCD display in sequence, and the first character "\*" will blink.

b) Rotate the **VOL** knob to change the first character (\*). The character will be changed from "A" to "Z", "0" to "9" and "\_", "-", "+", "space". Press the **SEL** button to confirm the character entered and the next character will blink for setting. Press the **AMS** button to delete the incorrect character.

c) When matched files was found, press the **SEL** button to start play the searched file.

If the file was not found, "NO MATCH" message will be visible on the display.


## Track/Folder Navigation

- During USB or SD card mode, press the **5/-10** button to go backward 10 tracks.  
Press the **6/+10** button to jump forward 10 tracks.
- During USB or SD card mode, press and hold the **5/-10** button to go back one folder.  
Press and hold the **6/+10** button to go up one folder. You can repeat this function depending on the number and level of folders.
- These buttons have no function if the USB device or SD card has no folders.

# REMOTE CONTROL


## Remove Insulating Sheet

The remote control comes with an insulating sheet attached to the underside of the remote control, as illustrated on the right. The remote control will not work until the insulating sheet is removed.



## Replace Lithium Battery Cell

1. When the lithium cell battery becomes weak, replace it as illustrated on the right.
2. Press and hold the movable block in the direction indicated by arrow 1. At the same time, pull the cell holder out of the remote control in the direction indicated by arrow 2.
3. Replace the old cell with a new one, making sure the (+) polarity is facing upward.
4. Re-insert the cell holder into the remote control.



- Cell leakage may cause damage to the remote control.
- Do not throw cells into fire, as this may cause an explosion.
- Keep battery cells out of reach of children.

## Remote Control Operation


Position the emitting window of the remote control toward the sensor window of the unit.

- The operation angle for front panel remote control reception is about 30 degrees.
- The distance between the emitting window of the remote control and the sensor window of the unit should remain less than 5 meters.

## REMOTE CONTROL (CONT.)

### Button Names and Locations

1. Power button
2. MUTE button
3. CLK (clock) button
4. LOUD (loudness) button
5. AMS (automatic music search) button
6. PREV (previous) button
7. EQ (equalizer) button
8. SRC (source) button
9. RPT (repeat) or 3 button
10. INT (intro) or 2 button
11. LOC (local) button
12. VOL (volume) button
13. SEL (select) button
14. BAND button
15. ST (stereo) button
16. >|| or 1 button
17. NEXT button
18. RDM (random) or 4 button
19. - 10 or 5 button
20. + 10 or 6 button



Note: To operate remote control, pull out the plastic from the battery compartment at back of remote control. Then point remote control at unit and start.

# TROUBLESHOOTING

| Symptom                                         | Cause                                      | Solution                                          |
|-------------------------------------------------|--------------------------------------------|---------------------------------------------------|
| No Power                                        | Car ignition not on                        | Switch ignition key to "ACC"                      |
|                                                 | Fuse blown                                 | Replace fuse                                      |
| Disc cannot be loaded                           | Another disc is already in the player      | Eject disc and insert new one                     |
| Disc cannot be read                             | Disc was inserted upside down              | Insert disc with label facing upward              |
|                                                 | Disc is dirty or scratched                 | Clean the disc or try to play a new one           |
|                                                 | Temperature inside the car is too high     | Allow vehicle to cool before using player         |
| No sound                                        | Volume turned down                         | Adjust volume to desired level                    |
|                                                 | Wiring not properly connected              | Check and repair wiring connection                |
| Operation keys not working                      | Front panel not properly fixed into place  | Reinstall the front panel                         |
|                                                 | Car interior is too hot                    | Allow vehicle to cool before using player         |
| Sound skips                                     | Installation angle is more than 30 degrees | Adjust installation angle to less than 30 degrees |
|                                                 | Disc is dirty or scratched                 | Clean disc or try to play a new one               |
| Radio does not work                             | Antenna cable not connected                | Insert antenna cable firmly                       |
| Automatic radio station selection does not work | Signals are too weak                       | Select a station manually                         |

# SPECIFICATIONS

---

## General

|                               |           |
|-------------------------------|-----------|
| Power Supply Requirement..... | DC 12V    |
| Current Consumption .....     | 15A MAX   |
| Maximum Power Output.....     | 50W x 4CH |

## Radio

### **FM**

|                          |                                       |
|--------------------------|---------------------------------------|
| USA/Europe.....          | 87.5 MHz - 107.9 MHz/87.5 - 108.0 MHz |
| Usable Sensitivity ..... | 30 dBu                                |
| I.F. Frequency.....      | 10.7 MHz                              |

### **AM**

|                          |                                   |
|--------------------------|-----------------------------------|
| USA/Europe.....          | 530 KHz - 1710 KHz/522 - 1620 KHz |
| Usable Sensitivity ..... | 20 dBu                            |
| I.F. Frequency.....      | 450 KHz                           |

## CD/USB/Card

|                            |                |
|----------------------------|----------------|
| Usable Audio Formats ..... | CD/MP3/WMA     |
| Pre-amp Output.....        | Front and Rear |
| Frequency Response .....   | 20 Hz - 20 KHz |
| S/N Ratio .....            | 60dB           |



## SOUND STORM LABORATORIES

3451 Lunar Court, Oxnard CA 93030

### TECHNICAL ASSISTANCE

[www.soundstormlab.com/technical-support/](http://www.soundstormlab.com/technical-support/)  
805.322.8794

## SDC24USA

MP3-COMPATIBLE CD AM/FM RECEIVER



0616

iPod® and iPhone® are registered trademarks of Apple Inc. in the U.S. and other countries.  
Sound Storm Laboratories is not affiliated with Apple Inc.