

SB18 All-Terrain Sound System

TABLE OF CONTENTS

- INFORMATION TO THE USER 2
- BEFORE YOU START 3
- GETTING TO KNOW YOUR SB18 4
- BEFORE YOU START 5
- BLUETOOTH OPERATION 6
- STREAMING MUSIC 7
- AUX INPUT 8
- USB INPUT 9
- REMOTE CONTROL 10
- INSTALLATION 11
- TROUBLESHOOTING 12
- WIRE DIAGRAM 13
- SPECIFICATIONS 13

For the latest information about this product please visit www.soundstormlab.com


TECH SUPPORT: 805-751-4855
www.soundstormlab.com/technical-support/

All rights reserved. No part of this publication may be reproduced, distributed, or transmitted in any form or by any means, including photocopying, recording, or other electronic or mechanical methods, without the prior written permission of SOUND STORM LABS.

All other trademarks and trade names are those of their respective owners.

Copyright © 2022 SOUND STORM LABS

Thank you for purchasing this




SB18 All-Terrain Sound System

Please read through these instructions carefully so you will know how to operate your model properly.

After you have finished reading the instructions, keep this document in a safe place for future reference.

THIS PACKAGE CONTAINS

- 1- SB18 All-Terrain Speaker System
- 1- Mounting Kit
- 1- Power Accessory Extension Adaptor
- 1- Remote control
- 1- User Manual
- 1- Warranty Card




INFORMATION TO THE USER

Bluetooth®

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks is under license.

Other trademarks and trade names are those of their respective owners.



- Do not touch others and
- In the case of immediate use
- Set your without dis
- BE SUR
- Do not t
- Use cau

WARNI

- Do not without pr
- Refer an
- The SB1 battery thr
- When w
- The gro
- The SB1 circumstan
- Use only
- Wash w
- Don't us
- DON'T
- DON'T
- DON'T

ENGLISH

ENGLISH

BEFORE YOU START

IMPORTANT SAFETY PRECAUTIONS

separate mobile equipment while driving a motorized vehicle - safe driving and safety consideration of said always be your highest priority.

ent you should notice smoke, strange noises or odor from this product, or any other abnormal signs, turn off the power and consult your dealer or the nearest authorized **SOUND STORM LABS** Service Center. Using this product in this condition may result in permanent damage to the system.

volume control at a low setting, then slowly increase the sound until you can hear it comfortably or until, or as described.

BEFORE TO OBSERVE THE FOLLOWING GUIDELINES:

not up the volume so high that you can't hear what's around you.

tion or temporarily discontinue use in potentially hazardous situations.

INSTALLATION PRECAUTIONS

NG - Always consult a professional installer

attempt to install or service this product by yourself. Installation or servicing of this product by persons with professional training and experience in electronic equipment and motorized vehicle accessories may cause and could expose you to the risk of electric shock, injury or other hazards.

you requires to a qualified **SOUND STORM LABS** Service Center.

80 can be powered from a vehicle's cigarette lighter / auxiliary power port, or hard wired directly to the ground or optional relay / accessory switch.

ing directly to the vehicle battery. Be sure to disconnect the batteries negative terminal wire before any wiring procedures. It is suggested that an optional fuse and fuse holder (not included) with a rating of 15 Amps be in line with the positive battery terminal.

ing and cable length should not exceed 150 inches (See wiring diagram).

8 has a weather resistant design, it should not be submerged in or under water under any circumstances.

the installation parts provided with the SB18

a mild soap or detergent and lukewarm water using a clean sponge or a soft cloth. Rinse well with water.

7. - Very Important

lean in hot sun or on very hot days.


use abrasive or highly alkaline cleaners on the main body

scraper the main body with razor blades, or other sharp instruments

ever use: gasoline, acetone or carbon tetrachloride.

CAUTION!!

Using other mounting methods may void this warranty



SOUND STORM
LABS

3

GETTING TO KNOW YOUR SB18

- A** SSL SB18
- 1** 3.5mm AUX-INPUT
- 2** CIGARETTE POWER CABLE ADAPTOR
- 3** LED POWER INDICATOR
- 4** CONTROL PANEL
- 5** USB JACK

BEFORE YOU START



PAIRING & DISCOVERING A NEW BLUETOOTH CONNECTION

- 1) Power on the **SB18** by plugging in the male cigarette lighter adaptor into **2** a female cigarette lighter receptacle.
- 2) Press the button **9**. The **SB18** will automatically go in to pairing mode:

ANDROID users:

- a. Go into the **Settings Menu** of your device
- b. Enter the **Bluetooth Menu**
- c. **TURN ON Bluetooth** and press **SCAN**
- d. "**SSL SB18**" will now be displayed under **AVAILABLE DEVICES**
- e. If prompted, enter passcode: "**0000**"


iOS users:

- a. Go into the **Settings Menu** of your iOS device
- b. Enter the **Bluetooth Menu**
- c. **TURN ON Bluetooth**
- d. "**SSL SB18**" will now be displayed
- e. If prompted, enter passcode: "**0000**"

NOTE: You have 2 minutes before you must restart this procedure over again.

3) If **SSL SB18** is not seen, repeat the above steps to refresh the "**Device List**"

4) When the connection is successful, you are now ready to stream music from your favorite media player to the **SB18**




SOUND STORM

5

BLUETOOTH OPERATION


ENGLISH

ENGLISH




RECONNECTION

- 1) Power on the **SB18** and your last paired **Bluetooth device**.
- 2) Press the button **(9)**. The unit will now automatically reconnect
- 3) If your device was previously paired with the **SB18**, but it wasn't the last paired device:
 - a. Ensure no other **devices** are currently paired
 - b. Enter the **Bluetooth Menu** on your device being paired
 - c. "**SSL SB18**" will display under **AVAILABLE DEVICES**
 - d. Choose the "**SSL SB18**" to reconnect
- 4) If the device is out of range from the **SB18**, it will disconnect automatically:
 - a. The **SB18** will automatically reconnect to the device once back in range


**Tips:**

To avoid battery exhaustion, be sure to occasionally run the vehicles engine while using this product.
Using this product without running the engine can drain the battery.

6


SOUND STORM


STREAMING MUSIC




- 1) Press the **(8) PLAY/PAUSE** once to start playing music or press the **PLAY** on your devices touchscreen
- 2) To skip songs or advance, press the **(11) NEXT TRACK** button
- 3) To select the previous song, press the **(6) PREVIOUS TRACK** button

VOLUME CONTROL

- 1) To raise the volume press the **(10) VOLUME UP** button or use your devices **VOLUME UP** button
- 2) To lower the volume press the **(7) VOLUME DOWN** button or use your devices **VOLUME DOWN** button

 **Tips:** For maximum audio performance, ensure your device Bluetooth volume is set to a minimum 75% level before stowing



SOUND STORM

ENGLISH

ENGLISH

AUX INPUT

The diagram illustrates the AUX input setup. It shows a male cigarette lighter adaptor (1) being plugged into a female cigarette lighter receptacle (2). A close-up of the control panel shows the AUX button (9) and the VOLUME DOWN (7) and VOLUME UP (8) buttons. The AUX input jack (12) is also shown. The diagram is labeled with numbers 1 through 12.

SB18 can play a
any device that has
headphone audio

AUX-IN OPERATION

- 1) Power on the **SB18** by plugging in the male cigarette lighter adaptor into the female cigarette lighter receptacle.
- 2) Press the button **(9)**. The **SB18** will automatically go in to **AUX** mode.
- 3) Connect the integrated 3.5mm **AUX-IN** cable **(1)** to your devices.
- 4) Route the wire back to **SB18**, and secure your device.

VOLUME CONTROL

- 1) To raise the volume press the **(10) VOLUME UP** button or use your device's volume controls.
- 2) To lower the volume press the **(7) VOLUME DOWN** button or use your device's volume controls.

Tip:

For maximum audio performance, ensure your device's volume is set to a minimum 75% level before starting playback.

SOUND STORM

USB INPUT

audio from a 3.5mm to jack.

into 2 a

device:


headphone jack

devices controls

ur devices controls

ce headphone ng

USB INPUT



USB IN OPERATION

- 1) Power on the **SB18** by plugging in the male cigarette lighter and female cigarette lighter receptacle.
- 2) Press the button (9). The **SB18** will automatically go in to auto.
- 3) Insert the USB Flash drive on (5) and play the music automatically.
- 4) Press the (8) **PLAY/PAUSE** once to start playing music or pause.
- 5) To skip songs or advance, press the (11) **NEXT TRACK** button.
- 6) To select the previous song, press the (6) **PREVIOUS TRACK** button.
- 7) To raise the volume press the (10) **VOLUME UP** button or use the volume knob.
- 8) To lower the volume press the (7) **VOLUME DOWN** button or use the volume knob.

Tips: USB can play music formats MP3 and WMA. USB can provide 1A current.

SOUND STORM

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

REMOTE CONTROL

English

English

REMOTE CONTROL OPERATION

1) Remote control receiver window

INSTALLATION

- 1) use the supplied adjustable bracket to secure to rails.
- 2) always recheck bracket before every ride

A line drawing of a roller coaster car chassis. A rectangular adjustable bracket with a circular adjustment knob is shown being attached to the top horizontal rail of the car's frame.

A line drawing of a hand using a coin to flip open a battery compartment cover. The cover is labeled 'OPEN' with an arrow pointing to the coin.

REPLACEMENT BATTERY - CR2025

The logo for Sound Storm, featuring the letters 'SS' in a stylized, bold font, with 'SOUND STORM' written below it and 'BY DESIGN' in smaller letters at the bottom.

N

000000

ENGLISH
ENGLISH

TROUBLESHOOTING

TROUBLE	CAUSE	SOLUTION
Unit will not turn on	The fuse is blown	Check / replace the fuse
	Main acc. switch not engaged	Turn switch to on
No sound is heard	Device volume is low / muted	Turn the volume up
	Device is paused or muted	Check your device volume status
Cannot pair Bluetooth	The Bluetooth function of the device is not enabled	Refer to the user's manual for the Bluetooth function
	The Bluetooth reception is poor	Move the device away from the obstacle between the device and the Bluetooth device
Unit has become unresponsive		Disconnect power for 10 seconds to reset
	Power glitch or interference	

SUPPORT

For the latest information about this product please visit www.soundstormlab.com

TECH SUPPORT: 805-751-4855
www.soundstormlab.com/technical-support/

DIMENSIONS

11

12

SOUND STORM
 LAB

